

# 912-AVA-HUB

## **Operation**

The 912-AVA-HUB is a device that allows the user to expand the number of dry contact connections from 1 to 3 when used in conjunction with the 912 AVA. The HUB requires no electric and should be wired as shown in the wiring diagram.

## **Installation**

Attach the 912-AVA-HUB to a wall or other structure using the mounting tabs located diagonally across from each other on the exterior of the hub. **DO NOT** open the hub module and try to fasten the housing by screwing through the enclosure. Doing so will void all warranties.

Please follow the attached wiring diagram for correct installation. Polarity is not an issue. Wiring should be done in compliance with all state & local codes.

# 912-AVA-HUB WIRING DIAGRAM

